SINGER 132W100

LIST

OF

PARTS



MACHINE No. 132w100

THE SINGER MANUFACTURING COMPANY

INDEX

P	AGE
CESSORIES	15
ORRIN WINDER	16
NEE LAFTER	17
ACHINE No. 132w100	7
UMERICAL LIST OF PARTS	19
BSOLETE PARTS	18
IREAD UNWINDER	17

Instructions for Ordering

In ordering from this list, use ONLY the PART number in the FIEST column.

The number stamped on a Sewing Machine Part is the number of the Single Part only, except when the part includes Set Serews, Clamping Screws, Studs and Rollers Spun on, Small Wires riveted, or Parts soldered together, etc., which it is necessary to furnish in combination.

Every combination of parts sent out has its specific number which, although not stamped on Parts (except in above cases) must be used when ordering the combination.

Each number always indicates the **SAME PART** in whatever list it appears, or for whatever Machine.

The letters after some of the numbers indicate the style of finish only, as follows:

- A. Hardened, Polished and Plated.
- B. Polished and Plated.
- C. Hardened only.
- D. Polished only.
- E. Soft, not polished.
- F. Hardened and Polished.
- H. Blued.

These letters MUST BE USED when they appear in the list and AFTER the number, as in the list.

In this series

200001 to 201500 are Screw Numbers.

201501 to 201800 are Nut Numbers.

201801 to 202000 are Roller Numbers.

202001 and upward are numbers of Machine Parts.


The figures in the second column refer only to the plate in which the illustration of the part is shown and are **NOT TO BE USED** in ordering.

Two or more numbers over a cut indicate that the difference between such parts is not visible in an illustration.

Parts marked with an asterisk (*) are furnished only when repairs are made at the factory.

LIST OF PARTS COMPLETE

FOR



MACHINE No. 132w100

For Making Madeira Eyelets

No.	Plate	Name
*238001		Arm with 202135
203087	14251	" Cap
200278π	14252	" " Screw
202248	14252	" " " Washer
203089	14251	" " Spool Holder Base
203090	14251	" " " " 203089
		with 200079 m and 204296
200585н	14252	Arm Cap Spool Holder Base Screw
204296	14251	" " " Wire
200079 n	14252	" " " " Hinge
		Screw
203088		Arm Cap and Spool Holder complete, Nos. 203087, 203090 and two 2005854
204235	14252	Arm Position Pin (2)
$200010 \mathrm{E}$	14252	" Screw (3)
202005	14252	" " Washer (3)
238002	14253	" Shaft with 200357E and 203100
202243	14251	" " Bushing (back) with
		202244

No.	Plate	Name
202244	****	Arm Shaft Bushing (back) Oil
		Packing (wick)
200341c	14252	Arm Shaft Bushing (back) Set Screw
224302	14251	Arm Shaft Bushing (front) with 202036 and 202260
202260		Arm Shaft Bushing (front) Oil Packing (wick)
200502в	14252	Arm Shaft Bushing (front) Oil Packing Thumb Screw
202036	14252	Arm Shaft Bushing (front) Position Pin
2003410	14252	Arm Shaft Bushing (front) Set
202634	14251	Arm Shaft Connection Belt
202635	14251	" " " Pulley
202000	21-0-	with 200327c, 200602E and two 202253
$200602\mathrm{E}$	14252	Arm Shaft Connection Belt Pulley Position Screw
2 00327c	14252	Arm Shaft Connection Belt Pulley Set Screw
202253	14252	Arm Shaft Connection Belt Pulley Spring Flange
203100		Arm Shaft Oil Packing (wick)
200357E	14252	" " " Stop Screw
202705	14253	Balance Wheel (belt groove 24 in. diam.) with 200328c and 200335c
20006211	14252	Balance Wheel Adjusting Screw
20008211 200328c	14252	" Position Screw
200328C 200335c	14252 14252	" Set Screw
*238006	1420	Bed with 238089
202258	12345	" Hinge Connection (2)
202256 200570E	14252	" " Screw (4)
210530	14252 14252	Bobbin
224416	14252	" Case Base
224417	142.72	" " Cap with 200598c.
201111		201016c and 224421
004410	14252	Bobbin Case Cap complete, Nos.
224418	14202	200964E, 210736, 224310 and 224417
224309	14252	Bobbin Case Latch
224310		" " 224309 with
		210735 and 224401
210735	14252	Bobbin Case Latch Fulcrum Pin
224401	14252	" " Lever
210736	14252	" " Spring
200964E	14252	" " Stop Screw
238008	14252	" " Stop
202036	14252	" " Pin (2)

No.	Plate	Name
2000920	14252	Bobbin Case Stop Screw
	14252	" " Tension Spring
201016c	14252	" " " " " " " Regulat-
		ing Screw
200598c	14252	Bobbin Case Tension Spring Screw
224419		Bobbin Case complete, Nos. 224416
22		and 224418
238009	14253	Face Plate
202135	14254	" " Position Pin
200473в	14254	" " Thumb Screw
*238010		Hook (sewing)
238011	14254	" 238010 with 200145u, 203101,
		224339, 238013 and three 200596r
238012		Hook and Bobbin Case complete,
2.,		Nos. 224419 and 238011
238013	14254	Hook Gib
200596r	14254	" " Screw
203101		" Oil Wick
200555 u	14254	" Serew
238014	14253	" Shaft
202321	14254	" " Bushing (back)
210943	14254	" " " (front)
$200346\mathrm{c}$	14254	" " Set Screw (2)
202661	14251	" " Connection Belt Pulley
		with 202324 and two $200378c$
$200378 \mathrm{C}$	14254	Hook Shaft Connection Belt Pulley
		Set Screw
202324	14254	Hook Shaft Connection Belt Pulley
		Spring Flange
202260		Hook Shaft Oil Packing (wick) (2)
224339	14254	" Washer Needle Guard
200145 п	14254	DCI CW
233122	14251	Needle Bar (hollow) with 200141F
202552	14254	" " Connecting Link
224341	14254	531,000
		with 202254
202254		Needle Bar Connecting Link Stud
		Oil Packing (wick)
200374c	14254	Needle Bar Connecting Link Stud
		Set Screw
200383c	14254	Needle Bar Connecting Link Stud
		Set Screw
*206891		Needle Bar Connecting Stud
206892	14254	200001
		with 200072c and 202330
202330	·	Needle Bar Connecting Stud Oil Packing (wick)
0.000=0	14954	Needle Bar Connecting Stud Pinch
200072c	14254	Serew
		BUIUW

No.	Plate	Name
224342		Needle Bar Crank with 200335c.
		200374c, 200383c, 200428c and 224341
238016	F1	Needle Bar Crank 224342 with
200020		202399, 202400, 202552, 206892 and
		224372
203172	14254	Needle Bar Crank Friction Washer
200428c	14254	" " Position Screw
200335c	14252	" " Set Screw
238017	14251	" " Frame with 200378c
238100		" " 238017 with 233122
210910	14254	" " " Hinge Stud with
		202277
202277		Needle Bar Frame Hinge Stud Oil
		Packing (wick)
200347c	14254	Needle Bar Frame Hinge Stud Set
		Serew
238018	14256	Needle Bar Frame Position Plate
238019	14256	
		Position Pin
2000820	10881	Needle Bar Frame Position Plate
		Screw
238020	14256	Needle Bar Position Indicator
$200178 \mathrm{p}$	14256	" " Screw
		(2)
238103	14256	Needle Bar Positioning Sleeve
202355	14256	" " Frie-
		tion Packing (brass)
238022	14256	Needle Bar Positioning Sleeve Fric-
		tion Spring
200382c	14256	Needle Bar Positioning Sleeve Fric-
		tion Spring Screw
238104	14256	Needle Bar Positioning Sleeve Stud
		(eccentric)
200378c	14254	Needle Bar Positioning Sleeve Stud
		Set Screw
$200141 \mathrm{F}$	14256	Needle Set Screw
238024	14251	" Vibration Regulator with
		200382c and 200437c
238025	14256	Needle Vibration Regulator Index
		Finger
$200159 \mathrm{F}$	14256	Needle Vibration Regulator Index
		Finger Screw (2)
200437e	14256	Needle Vibration Regulator Posi-
		tion Screw
200382c	14256	Needle Vibration Regulator Set
		Screw
$200536\mathrm{c}$	14256	Needle Vibration Regulator Stop
		Screw

No.	Plate	Name
201521c	14256	Needle Vibration Regulator Stop
,		Serew Nut
201459n	14256	Needle Vibration Regulator Thumb
0.4574	14256	Stop Screw
20157111	14250	• •
238036	14251	Stop Screw Nut
238037	14255	" " Crank with 202277
238038		" " Bracket with
200000	14255	
000105	1.4050	two 222425
222425	14256	Needle Vibrator Crank Bracket Po-
000010	1.4050	sition Pin
200046c	14256	
2.000	1.1.75.0	Screw (lower)
200020a	14256	Needle Vibrator Crank Bracket Screw (upper)
238039	14255	Needle Vibrater Crank Cover
2000541	14256	" " Screw
200000000	17270	(2)
238040	14256	Needle Vibrator Crank Driving
200040	19200	Crank (lower) with 200362c and
		200437c
200437c	14256	Needle Vibrator Crank Driving
		Crank (lower) Position Screw
200362€	14256	Needle Vibrator Crank Driving
		Crank (lower) Set Screw
238043	14256	Needle Vibrator Crank Driving
		Crank (upper) with 200382c and
		200437c
200437c	14256	Needle Vibrator Crank Driving
		Crank (upper) Position Screw
200382c	14256	Needle Vibrator Crank Driving
		Crank (upper) Set Screw
238041	14256	Needle Vibrator Crank Driving
		Crank Connection
2002731:	14256	Needle Vibrator Crank Driving
		Crank Connection Hinge Screw
		(2)
238042	14256	Needle Vibrator Crank Link with
		202277
202277		Needle Vibrator Crank Link Oil
		Packing (wick)
202277		Needle Vibrator Crank Oil Packing
		(wick)
238029	14258	Needle Vibrator Eccentric with
		200382c and 201461c
238030	14255	Needle Vibrator Eccentric Connec-
		tion
201461c	14258	Needle Vibrator Eccentric Position
		Screw

No.	Plate	Name
200382c	14256	Needle Vibrator Eccentric Set
		Screw
238031	14253	Needle Vibrator Eccentric Shaft
238032	14255	££
		Bushing
200383c	14254	Needle Vibrator Eccentric Shaft
		Bushing Set Screw
238035	14255	Needle Vibrator Eccentric Shaft
		Driving Gear with two 200378c
200378c	14254	Needle Vibrator Eccentric Shaft
		Driving Gear Set Screw
238033	14255	Needle Vibrator Eccentric Shaft
		Gear with two 200378c
238034	14255	Needle Vibrator Eccentric Shaft
		Gear Cover with two 213692
213692	14258	Needle Vibrator Eccentric Shaft
		Gear Cover Position Pin
200566р	14258	Needle Vibrator Eccentric Shaft
		Gear Cover Screw (2)
200378c	14254	Needle Vibrator Eccentric Shaft
		Gear Set Screw
238097	14255	Presser Bar (hollow) with 201462F
238044	14258	" " Bushing
200347c	14254	" " Set Serew
238045	14258	" " Lifting Releasing Lev-
		er Bracket
200260D	14258	Presser Bar Lifting Releasing Lev-
		er Bracket Guide Screw
238046	14258	Presser Bar Lifting Releasing Lev-
		er Bracket Spring
202337	14258	Presser Bar Position Guide
202338	14258	" " Lever
		with 200086F
200086г	14258	Presser Bar Position Guide Lever
		Pinch Screw
200352c	14258	Presser Bar Position Guide Set
		Screw
238047	14258	Presser Bar Spring
238048	14258	" " Stop Rod
200492 B	14258	" " Thumb Screw (pres-
		sure regulating)
201637в	14258	Presser Bar Thumb Screw Check
		Nut
$200363\mathrm{c}$	14258	Presser Bar Thumb Screw Set
		Screw
202355	14256	Presser Bar Thumb Screw Set
		Screw Packing (brass)
238051	14261	Presser Foot, for evelets 🐇 in.
		diameter

No.	Plate	Name
238098	14259	Presser Foot Lifter with 200362c
2003620	14256	" " Set Screw
238099	14259	" " Lifting Lever
201462⊬	14359	" " Serew
5596	14259	Starting Bell Crank
5599	14259	" " " Bracket
178F	14259	" " " Screw (2)
5601	14259	" " " Hinge Pin
5735	14259	" " Spring
5598		Starting Bell Crank complete, Nos.
		5596, 5599, 5601 and 5735
238078	14253	Starting Shaft
238080	14257	" " Crank with 200382c
		and 200437c
238081	14257	Starting Shaft Crank Connecting
		Rod with two 202302
202302	14259	Starting Shaft Crank Connecting
		Rod Cotter Pin
200437c	14256	Starting Shaft Crank Position
		Screw
200382c	14256	Starting Shaft Crank Set Screw
238082	14257	" " Spring
238028	14259	" " Collar with
		200098F
200098F	14259	Starting Shaft Spring Collar Set
		Screw
238084	14259	Take-up (auxiliary)
224372	14259	" Lever
202399	14259	" " Driving Stud with
		202277
202277		Take-up Lever Driving Stud Oil
		Packing (wick)
202400	14259	Take-up Lever Hinge Stud with
		202423
202423		Take-up Lever Hinge Stud Oil
	*	Packing (wick)
200363c	14258	Take-up Lever Hinge Stud Set
•		Screw
202402	14260	Tension Disc (back)
202403	14260	" " (front)
224402	14260	" Release Lever
224403	14260	" " 224402 with
		200289F, 201537u and 224404
200289е	14260	Tension Release Lever Hinge Screw
20153711		
2		Nut
224404	14260	Tension Release Lever Hinge Stud
200355c		16 16 16 16
		Set Screw

202404	No.	Plate	Name
202405	202404	14260	Tension Release Plunger
204270	202405	14260	
200625F	204270	14260	
204925	$200625 \mathrm{F}$	14260	
204925	$200084\mathrm{F}$	14260	" " Set Screw
201572B 10881	204925	14260	
238101 14260 Tension complete, Nos. 200625F, 201572R, 202402, 202403, 202405, 202410 and 204270	201572 B	10881	
202410 and 204270	238101	14260	
2011848 14260 Thread Controller Bearing (screw)			201572B, 202402, 202403, 202405,
201637R 14258 " " " " Check Nut.			202410 and 204270
202402 14260 " " Disc	$201184\mathrm{n}$	14260	Thread Controller Bearing (serew)
224405 14260 " " Cap 2005770 14260 " " " Screw 224373 14260 " " Releasing Plunger 224374 14260 " " Releasing Plunger 224375 14260 Thread Controller Releasing Plunger 202410 14260 Thread Controller Spring 202411 14260 " " " Stop 20412 14260 " " " Stop 20413 14260 " " " Stop 202410 14260 " " " Stop 200132c 14260 " " " Stop 224406 14260 Thread Controller complete. Nos. 200577u. 201184a. 201637a. 224373. 224374. 224376. 224405 and two 202402 238085 14261 " " " 238085 14261 " " Screw 200582u 14261 " " " 238087 14257 Throat Plate 238092 14261 " " Position Pin 238095 14261 " " Spur, for evelets in. in. diameter " " " " " 238088	$201637\mathrm{B}$	14258	" " Check Nut.
224405 14260 " " " Cap 2005770 14260 " " " Position Pin . 224373 14260 " " Releasing Plunger 224374 14260 " " Releasing Plunger 224375 14260 " " " " " " Roller 24376 14260 Thread Controller Releasing Plunger 202410 14260 Thread Controller Spring " " Stop 202411 14260 " " " Stop " " Serew 224406 14260 " " " Stop " " Serew 224406 14260 Thread Controller complete. Nos. 2005770, 201184B, 201637B, 224373, 224374, 224374, 224376, 224405 and two 202402 238085 14261 " " Screw 2005820 14261 " " Screw 238087 14257 Throat Plate 238092 14261 " " Position Pin 238095 14261 " " Spur, for evelets sin, diameter 238088 Throat Plate Spur Locking Slide 238088 Throat Plate complete, Nos. 238087.	202402	14260	" " Disc
20057711 14260 " " " Position Pin	224405	14260	
224373 14260 " " Releasing Plunger 224374 14260 " " Releasing Plunger 224375 14260 " " " " " " Roller 224376 14260 Thread Controller Releasing Plunger Spring 202410 14260 Thread Controller Spring 202411 14260 " " " Stop 204406 14260 " " " Stop 224406 14260 " " " Stop 224374 224376 224373 224374 224376 224405 and two 202402 238085 14261 " " Screw 2005820 14261 " " Screw 238087 14261 " " Sorew 238089 14261 " " Position Pin 238092 14261 " " Spur, for evelets sin, diameter 238095 14261 Throat Plate Spur Locking Slide 2003210 14261 " " " " " Screw " " " " " 238088 Throat Plate complete, Nos. 238087.	$200577 \mathrm{H}$	14260	
224374 14260 " "Releasing Plunger 224375 14260 " " " " " " Roller Roller 224376 14260 Thread Controller Releasing Plunger Spring 202410 14260 Thread Controller Spring " " Stop 202411 14260 " " " Stop " " Serew 224406 14260 " " " Stop " Serew 224406 14260 Thread Controller complete, Nos. 2005770, 2011846, 2016376, 224373, 224373, 224374, 224376, 224405 and two 238085 14261 Thread Guide " " Screw 2005820 14261 " " Screw 238087 14261 " " Position Pin 238092 14261 " " Spur, for evelets sin, diameter 238095 14261 Throat Plate Spur Locking Slide 2003210 14261 " " " " " Screw " " " " 238088 Throat Plate complete, Nos. 238087.	224373	14260	
Roller R	224374	14260	
224376	224375	14260	6 46 46
ger Spring Thread Controller Spring Stop St			Roller
202410	224376	14260	Thread Controller Releasing Plun
202411 14260 " " " Stop 200132c 14260 " " " Screw 224406 14260 Thread Controller complete, Nos. 200577n, 201184n, 201637n, 224373, 224374, 224376, 224405 and two 202402 202402 238085 14261 Thread Guide 200086c 14258 " " Screw 200582n 14261 " " Screw 238087 14257 Throat Plate 238092 14261 " " Position Pin 238095 14261 " Spur, for evelets sin, diameter 238095 14261 Throat Plate Spur Locking Slide 200321b 14261 " " " " " " 38098 Throat Plate complete, Nos. 238087.			ger Spring
200132c 14260	202410	14260	
224406	202411	14260	Stop
20057711, 201184B, 201637B, 224373, 224374, 224376, 224405 and two 202402		14260	20.Lo.A.
224374, 224376, 224405 and two 202402 238085 14261 Thread Guide 210592 14261 " " Screw 200086c 14258 " " Screw 200582n 14261 " " " " 238087 14267 Throat Plate 238089 14261 " " Position Pin 238092 14261 " " Spur, for evelets and in, diameter 238095 14261 Throat Plate Spur Locking Slide 2003210 14261 " " " " " " Screw 238088 Throat Plate complete, Nos. 238087.	224406	14260	
202402			
238085 14261 Thread Guide 210592 14261 " " Screw 200086c 14258 " " Screw 200582u 14261 " " " " " 238087 14257 Throat Plate 238089 14261 " " Position Pin 238092 14261 " " Spur, for evelets at in, diameter 238095 14261 Throat Plate Spur Locking Slide 200321b 14261 " " " " " " " Screw 238088 Throat Plate complete, Nos. 238087.			
210592 14261 " " Screw 200086c 14258 " " Screw 200582n 14261 " " " " 238087 14257 Throat Plate 238089 14261 " " Position Pin 238092 14261 " " Spur, for evelets at in, diameter 238095 14261 Throat Plate Spur Locking Slide 200321b 14261 " " " " " " Screw 238088 Throat Plate complete, Nos. 238087.			202402
200086c 14258 " " Screw	238085	14261	Thread Guide
200582	210592	14261	((),)
238087 14257 Throat Plate 238089 14261 " " Position Pin 238092 14261 " " Spur, for evelets as in, diameter 238095 14261 Throat Plate Spur Locking Slide 2003210 14261 " " " " " " Screw 238088 Throat Plate complete, Nos. 238087.	200086c	14258	" " Serew
238089 14261 " " Position Pin	200582 n	14261	
238092 14261 " " Spur, for evelets at in. diameter	238087	14257	
238095 14261 Spir, for evelets and in. diameter	238089	14261	" Position Pin
238095 14261 Throat Plate Spur Locking Slide 290321b 14261 " " " " " " " " " " " " " " " " " " "	238092	14261	" "Spur, for evelets 👸
290321b 14261 " " " " " " " " " " " " " " " " " " "			in. diameter
Screw			•
238088 Threat Plate complete, Nos. 238087,	$200321\mathrm{p}$	14261	tt tt tt
- The transfer of the complete of the contract			Screw
238095 and three 200321p	238088		
			238095 and three 200321b

ACCESSORIES


No.	Plate	Name
210530	14252	Bobbin
*225482		" Case Screw Driver Blade
*225183		" " " Handle
225497	12345	Bobbin Case Screw Driver com-
		plete, Nos. 225482 and 225483
238096		Drip Pan with four wood screws
		$\frac{1}{2}$ in No. 5
87561		Embroidery Hoop
234168		Eyelet Piercer with 200473B
234469		" " Holder
$200473 \mathrm{g}$	14254	" "Thumb Screw
234470	14262	Eyelet Piercer (adjustable), for
		eyelets from δ_1 to $\frac{1}{4}$ in. diam.,
		complete, Nos. 234468 and 234469
234462		Eyelet Punch, .067 in. diameter
234463		" .055 in. diameter
234464	-	" " " " " diameter
234465	14262	" g. in. diameter ,
234466		" " $arepsilon_i$ in diameter , , .
234467		" " $\frac{3}{32}$ in, diameter
234484		" Cutting Block (fibre)
234485		" " Mallet (wood)
41400	12345	Machine Rest Pin (wood)
135×7		Needles, six, size 12
36578	12345	Oiler with 36579
36579	12345	" Spout, $3\frac{1}{2}$ in, long, with 120117
120117		" " Washer (leather)
238049	****	Presser Foot, for eyelets $\bar{\phi}_t$ in.
		diameter
238050		Presser Foot, for eyelets $\frac{\pi}{64}$ in.
000050		
238052	# 1 1 The second	Presser Foot, for eyelets 3 in. diameter
238053		Presser Foot, for eyelets 4 in.
		diameter
*225484		Screw Driver Blade
*225485		" " Handle
225498	12345	Screw Driver complete (71 in.
		long), Nos. 225484 and 225485
222956	•	Thread Unwinder Spool Weight
222962	14257	
		222956 with 2455, 200011E, 202482, 202483 and 222961


• • •			Accessories	
No.	Plate	Name	No. Plate Name	
2455	14262	Thread Unwinder Spool Weight Tension Disc (lower)	225433-10885 Bobbin Winder and T	
202482	14262	Thread Unwinder Spool Weight Tension Disc (upper)	et Base 225382 10885 Universal Bobbin Wit	ider complete,
200011E	14262	Thread Unwinder Spool Weight Tension Disc Screw	Nos. 200056 E. 2000 202473, 202478 . 22 225444, 225453 to :	25381, 225433,
202483	14262	Thread Unwinder Spool Weight Tension Disc Spring (brass)	10 225460, 225462, 2 wood screws 3 in.,	28026 and two
222961	14263	Thread Unwinder Spool Weight Thread Guide		
238090		Throat Plate Spur, for eyelets $\hat{\phi}_1$ in diameter	KNEE LIFTER	
238091		Throat Plate Spur, for eyelets ϵ_1^T in diameter	2763 14253 Knee Lifter Rock Sh 7539 14253 " " " "	
238093		Throat Plate Spur, for eyelets $\frac{\partial}{\partial t}$ in diameter	(back) with two w in., No. 10	
238094		Throat Plate Spur, for eyelets { in. diameter	20093 14253 Knee Lifter Rock ((front) with two v	
225554	12345	Wrench (steel)	in., No. 10	aft Knee Arm
		BOBBIN WINDER	2768 " " " " " " " " " " " " " " " "	2767
	Sw	ring Automatic, Right Hand	2766 14253 Knee Lifter Rock Sh Hub with 356c	
$\frac{225453}{225454}$	10884 10884	Frame with 202277 and 225438 " Hinge Pin	356c 14262 Knee Lifter Rock Sh Hub Set Serew	
202277 225438	10884	" Oil Packing (wick) " Well Cap	2767 14253 Knee Lifter Rock Sh Plate with 356c	
225455 225456	10884 10884	" Spring" " " Plunger	356c 14262 Knee Lifter Rock Sh Plate Set Screw .	
202473 200105c	10885 10884	Pulley with 200105c	6337 14253 Knee Lifter Rock Bracket with two:	
225381 225444	10884 10884	Spindle	2778 14253 Knee Lifter Rock Bracket Hook	
200056E 225458	10884 10884	" " Screw" " " Thumb Lever	356c 14262 Knee Lifter Rock Bracket Hook Set	Shaft Lifting
225459 225460	10884 10884	" " " Hinge Stud	356c 14262 Knee Lifter Rock Bracket Set Screw	Shaft Lifting
202478 20029911	10884 10884	" " Trip Lever" " " " Hinge Screw	2770 14253 Knee Lifter Rock S with 356c	•
225461 200082D	10881 10881	Tension Bracket with 201499B " " Screw	356c 14262 Knee Lifter Rock S Set Screw	. ,,
$228026 \\ 2102 \\ 202407$	10884 10881 10881	" " " Washer " Disc " Spring	238102 14253 Knee Lifter Rock S Nos. 2763, 2768, 27 7539 and 20093	haft complete, 70, 2778, 6337,
201499B 201572B	10881 10881 10881	" Stud " " Thumb Nut Bobbin Winder Tension Bracket	THREAD UNWIND	ΕR
225462	10001	complete, Nos. 201572B, 202407, 225461 and two 2102	225395 14263 Spool Rest (for two 201048c	. /

No.	Plate	Name
225388	14263	Spool Rest Rod
200383c	14254	" " Set Screw
$201018\mathrm{c}$	14262	" Set Screw
202490	14263	" Stand with 200383c
60913	14263	" Weight
225391	14263	Thread Guide
201696 j	14262	" Lock Nut
225392	14263	" Rod with 208E and
		225393
208e	14262	Thread Guide Rod Screw
225393	14262	" " Washer
225396	14263	Thread Unwinder (for two spools)
		complete, Nos. 2016961, 202490,
		225388, 225392, 225395, two each
		60913, 225391 and three wood
		screws 3 in., No. 13

OBSOLETE PARTS

238021	14262	Needle	Bar	Positioning	Sleeve	
238023	14262	**	"	"	"	Stud



































PLATE 14254-FULL SIZE







PLATE 14255-ONE-HALF SIZE 238032 238097










PLATE 14260-FULL SIZE




PLATE 14261-FULL SIZE

